



Fitting & Care Instructions For Chromed Alloy Wheel Lock Covers (version 1.1, 21 October 2021)

To create the high-quality finish of the chromed Alloy Wheel Lock Covers, the lock cover has been moulded from resin. Care should be taken with assembly and cleaning to preserve the cap and polished finish.

When fitting the cap the end of the retaining strip should be bent to form a simple hook, which will prevent the cap becoming lost. When doing so, support the strip at the cap end between two fingers, and bend the other end simply like so:



To care for the finish, remove any dirt with a mild soap solution. Non-abrasive polish may be used with a detailing or soft microfibre cloth.