



downward it *will not operate*.

## Fitting your *Prestige Parts*<sup>®</sup> Shock Absorber

*Prestige Parts*<sup>®</sup> Shock Absorbers must be fitted with the **dust cover up** as per the direction arrow on the body of the shock absorber. While it is possible to fit a rear shock absorber with the dust cover



Before fitting the shock absorber, turn it the right way up (dust cover to the top), and operate it a few times by hand to prime the damper, taking care not to over-compress so that the lip on the operating shaft does not pass into the seal in the shock absorber body. If you over-compress the shock absorber it will not return and oil will leak past the seal, invalidating the warranty.