



UE46044-X Fuel Level Transmitter is a genuine replacement for the original metal transmitter fitted by the factory. If you are replacing the metal transmitter you will need to re-use the metal reinforcement plate. To do so you must modify this plate through the introduction of three holes (or one long hole) to accommodate the wiring terminals, which are in a different position to the original transmitter.

